

34 11 Front Brake

	Type	Thread	Tightening specification	Measure
1AZ Brake disc to wheel hub	E81, E82, E87, E88, E90, E91, E92, E93		Replace screws	16 Nm
2AZ Brake anchor plate to swivel bearing	E81, E82, E87, E88, E90, E91, E92, E93	M12x1.5	Replace self-locking or microencapsulated screws	110 Nm
3AZ Guard plate to swivel bearing	E81, E82, E87, E88, E90, E91, E92, E93	M6	Replace self-locking or microencapsulated screws	12 Nm
4AZ Guide screw (socket head cap screw)	E81, E82, E87, E88, E90, E91, E92, E93	WAF 7	Replace self-locking or microencapsulated screws	30 Nm
5AZ Guide screw (hexagon screw)	E81, E87, E88, E90	WAF 13	Replace self-locking or microencapsulated screws	35 Nm