BMW

MILES	30,000	35,000	40,000	45,000	50,000	55,000	60,000	65,000	70,000	75,000	80,000	85,000	90,000	95,000	100,000	105,000	110,000	115,000	120,000
Cost based on a major online parts supplier- I'm sure there are less expensive alternatives, but I believe in 'worst case scenario'	**$924.23**	**$150.02**	**$150.02**	**$250.68**	**$150.02**	**$150.02**	**$924.23**	**$150.02**	**$150.02**	**$250.68**	**$150.02**	**$150.02**	**$924.23**	**$150.02**	**$150.02**	**$250.68**	**$150.02**	**$150.02**	**$2,020.19**
Date Performed:																			
ENGINE OIL SERVICE																			
Engine oil and oil filter, change. (CBS prompts based on oil condition sensor monitoring. See 119 Lubrication System.)	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Brief diagnostic tests:	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
• Check Control, check messages.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
• Indicator and warning lights, scan for fault codes using BMW scan tool or equivalent.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
• CBS display, reset.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
• Tires, check tread, adjust pressures.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
• Tire pressure monitor, reset.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Parking brake, check operation, adjust as necessary.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Washer fluid, top off	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Table b. CBS prompted service																			
Front brake pads, replace. (CBS prompts based on pad thickness.)																			
Rear brake pads, replace. (CBS prompts based on pad thickness.)																			
Brake fluid, change every 2 years. (CBS prompts based on time elapsed since last change)																			
Cabin microfilter, change. (Every 15,000 miles.)	X			X			X			X			X			X			X
Table c. Additional services																			
Every 15,000 miles																			
• Air filter element, replace. Reduce change interval in dusty conditions.	X			X			X			X			X			X			X
Every 30,000 miles																			
• Dual Clutch transmission fluid {DCT), replace.	X						X						X						X
• Limited Slip Differential fluid	X						X						X						X
• Power Steering fluid flush	X						X						X						X
• Spark plugs, replace.	X						X						X						X
• Inspect/change brake pads	X												X						X
Every 60,000 miles																			
• Inspect/change brake rotors							X												X
Every 120,000 miles																			
• Oxygen sensors, S65 engines, replace.																			X
Note: BMW states that engine coolant, manual transmission fluid, and differential fluid fluid are life-time fluid and do not require replacement.																			

Table d. Vehicle check																			
Horn, headlight flasher, hazard warning flasher, check operation,	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Instrument cluster and control lighting, blower, check operation	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Lighting system (dome lights, glove compartment light, flashlight, trunk or cargo compartment lights, turn signals, hazard warning flasher, back-up lights, brake lights, license plate lights, check operation.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Safety belts, check condition and function.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Wipers and washers, check.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Body, check for corrosion.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Tires, check tread depth, wear pattern, condition , inflation pressure, correct pressure as necessary.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Run-flat indicator, initialize.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Battery, check state of charge, charge as required.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Power steering fluid, check fluid level.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Airbags, inspect for torn covers, damage or attached stickers.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Mirrors, inspect.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Engine coolant, check level and concentration.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Windshield washer, intensive cleaning system, check protection level, fluid level, top off if necessary.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Brake system connections and lines, check for leaks, damage and correct positioning.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Underbody (transmission, rear axle, fuel lines, exhaust system) check for damage, leaks and corrosion.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Steering components, check for clearance, leaks, damage and wear.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Road test, check for performance, braking, steering, suspension, noises.	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X